



## TIVO Remote Control Setup


**Setup the TiVo Remote to control your TV's Power, Volume, and Mute**


**How to go to the REMOTE CONTROL SETUP screen:**

1. Press the TiVo button  and press OK/Select
2. Arrow left to  **Menu** and press OK/Select
3. Arrow down to **Settings** and press OK/Select
4. Arrow down to **Remote, Cable CARD, and Devices** and press OK/Select

**Once on REMOTE CONTROL SETUP:**

1. Arrow down to **Set TV Power, Volume, and Mute** and select the brand of your TV from the list. Use the up/down arrow or the Ch (channel) up/down buttons on your TiVo remote to highlight your TV brand and press OK/Select. (TV Remote Codes will appear on your TV screen).





2. Enter the first code listed and follow the instructions on the screen.
3. Test the TV power button on the TiVo remote to see if it turns off/on.
  - If the first code does not work, repeat the instructions to enter the second remote control code, and so forth, until you find a code that works.
  - If none of the codes shown on the screen works, you can get the remote to search its pre-programmed list for a code that will control your TV/sound system. Contact us for assistance.